

No More Gaps® Multipurpose

Description

No More Gaps® Multipurpose gap filler delivers a smooth finish and because of its superior flexibility and low shrinkage, those unsightly gaps and cracks won't re-appear

Product Information

Packaging	Size	Colour
Cartridge	475 grams	White
Cartridge	475 grams	Brown
Squeeze Ezy	380 grams	White
Tube	320grams	White

Uses

Use No More Gaps® Multipurpose for small gaps where movement occurs such as: architraves, cornices, cabinets, skirting boards, wall joints, window frames and door frames. It is suitable for materials such as aluminium, brick and masonry, cement sheeting, ceramic tiles, glass, particle board, plasterboard and wood.

Technical Features

- Superior Flexibility
- Interior and Exterior
- Paintable with water and oil based paints
- Maximum durability
- Flawless finish
- Superior adhesion

Technical Details

Property	Typical Result
Appearance	Smooth paste
Technology	Water Evaporation
Skin time	20 minutes*
Flow/sag/slump	Less than 2mm (MII-S-8802E)
Shore A Hardness	Greater than 40
Ultimate Tensile Strength	0.6MPa (ASTM D412)
Peel Strength	5kgcm-1 (Anodised Aluminium)
Joint Movement Capability	Up to +/- 20% (ISO 9046)
Maximum Elongation	Up to + 300% (ASTM D412)

Indicative data only, not intended for preparation of specifications

Paint Type	Paint Over Time*
Gloss	30 minutes*
Semi Gloss	30 minutes*
Low Sheen	30 minutes*
Flat	24-48 hours*
Undercoats	24-48 hours*

How To Use

Application

1. Surface must be clean, dry and free from dust.
2. Cut seal and nozzle and fit to cartridge. Insert into caulking gun
3. Apply with caulking gun, forcing product into gap.
4. Smooth with a wet finger/spatula
5. Clean up with a damp cloth immediately.
6. Allow surfaces to skin prior to painting (approximately 30 minutes*).
7. Do not store or apply below 5°C. Protect from water until firmly skinned. Allow for longer skin and cure times in damp conditions

Clean Up

Uncured product may be removed with water. Cured product can be removed by sanding and scraping

Handy Hints

- *Some water based undercoats and flat paints may crack on drying. To reduce this effect, allow to cure for 24 hours in small gaps or 48 hours in larger gaps before painting with such paints or oil based paints
- Always paint with a quality paint to increase durability

Limitations

- Not recommended for gaps between tongue and groove boards and weatherboards, use **No More Gaps® Exterior & Weatherboard**
- Where movement is excessive or for areas where contact with water is frequent, use the appropriate **Selleys® Silicone Sealants**

No More Gaps® Multipurpose

Warnings, First Aid and Shipping Information

This information can be located on the SDS found on the Selleys website – www.selleys.com.au or www.selleys.co.nz